

ALIGATOR



S5080 Duo 4-core HD LTE
Quick Guide

Contents

Before you start.....	2
DUAL SIM function.....	3
Important instructions.....	4
Insert battery and SIM card.....	9
Mobile controls.....	11
Switch On / Off.....	12
Activation and screen unlock.....	13
Android system.....	14
Basic control.....	14
Making calls.....	20
Messages.....	24
Choice of SIM for data connection....	26
Photography.....	26
PC connection.....	28
Smart casing.....	30
Safety and ecology.....	32
Declaration of conformity.....	34

Before you start

**Thank you for buying of our
ALIGATOR mobile phone.**

Before you start please read carefully this instruction manual.

DUAL SIM function

Your mobile phone can be operated with 1 or 2 SIM cards. If you insert only one SIM card the mobile phone works as an ordinary mobile phone.

In case you insert 2 SIM cards at the mobile phone both are active at the same time. It means you can be called on both SIM cards at the same time without any switch

between them. Both cards are on line.

Important instructions

- Do not use the mobile phone in the prohibited areas
- Do not use the mobile phone while driving the car
- Do not use the mobile phone near the medical appliances without having the confirmation that the radio waves do not influence its function.

- Mobile phone can influence the function of the cardiac pacemakers or other implanted appliances – please consult your medical doctor
- Switch off the mobile phone in the aircraft
- Do not use mobile phone near the petrol stations. Always switch off the mobile phone near explosives.
- Use only the original batteries supplied by the producer. Danger of

damage of the mobile phone or explosion.

- Do not throw the battery in the fire nor expose it to the temperatures over $+60^{\circ}\text{C}$. Danger of explosion or fire.
- SAR – mobile phone meets all prescriptions for maximal emission of electromagnetic radiation.
- Please keep the mobile phone 2.5 cm away from the body while calling. You lower by that the quantity of electromagnetic

radiation absorbed by your body.

- Handle the mobile phone with care, protect it from falling on the ground, from mechanical damage, impurity or high temperatures. Never pick it to pieces !
- Do not place the mobile phone or its holder in the area above the airbag in the car
- Keep it out of reach of children. It contains small parts that could be swallowed or may hurt

- Software and hardware of the mobile phone are continuously innovated. The importer reserves the right to alter the instruction manual or particular functions of the mobile phone without a prior notice.
- If your phone is equipped with E-compass (not standard), its function can be affected by the surroundings and by the used accessories, eg. housing, etc. E-compass shows only a very rough direction and can not be a

substitution of ordinary compass. Inaccuracy E-compass is not grounds for complaint.

Insert battery and SIM cards

Slip your nail at the slot at the back side of the mobile phone and carefully pull down the cover.


Insert firstly one or two SIM cards at the prepared slots. Insert SIM and also MicroSD memory cards (if you have) as per the picture.

Insert the battery. Make sure that the battery clicks smoothly into the slot in the

mobile phone. Put the battery cover back.

Place the cover on the back side of the mobile phone and press gently around the circuit until the cover clicks properly on its place.

Mobile controls



1. Button : Offer

2. Button : Main screen

3. Button : Backwards

4. Volume

5. Button : Switch On / Off

6. Earphones

7. Headphone connector

8. Front camera

9. Micro USB connector Switch On / Off

Switch On / Off

To **Switch On** - press the button **(5)**. The start of the mobile phone can take few seconds.

When you first switch on the setup wizard displays. Choose your language and follow the instructions on the screen.

To **Switch Off** – press and hold the button **(5)** till the indicator window of a switch off appears on display. Confirm it and the mobile phone will turn off.

Activation and screen unlock

The screen will turn off automatically after a certain time of inactivity. You can turn on/off the screen by a short press of the button **(5)**.

It is necessary to unlock the screen after the activation. Put your finger on a „Lock“ symbol and move it in the right direction. The screen will be unlocked.

Android system

Your mobile phone is provided with the ANDROID operating system. The device is in reality a small personal computer that can be connected with internet from which you can download many useful applications (Goggle Play)

Basic control

Meaning of the touch buttons

(1) to (3)

- (1) **Menu** – serves to display the offer of items on actual screen or in the launched application.

- (2) **Main screen** – a short press serves to return to a main screen. A long press displays the list of launched applications.

- (3) **Backwards** – serves to return by one level back (jump on the preceding screen, closing of offers or dialog windows on the screen.)

System control

Your mobile phone can be controlled either by above mentioned buttons or with the help of touch screen.

By clicking on them you can choose the items , confirm dialogue windows and graphical buttons on the screen.

Google account

It is necessary to create the Google account which can be set up in following simple steps:

- 1.Press the button **Menu (1)** and choose „Set up“
- 2.Select **Accounts and synchronisation** in menu and choose **Add Account**

3. Further follow instructions on the screen

Main screen

Your main screen is divided into more pages that can be displayed by moving of your finger to the left/right.

On the main screen you can place the short cuts of icons of applications and links or widgets.

Widgets are miniapplications that enable to display some data of icons (clock, weather..)

Applications

All installed applications can be displayed by the button placed in the middle of the lower part of the main screen.

In standard equipment of the mobile phone you can find applications for making calls, sending messages and e-mails or many other useful applications.

There are thousands of various applications suitable for Android system but not all of them can work properly in your mobile phone.

Before buying of any new application please try first its free of charge version if it works correctly in your mobile phone.

Information and display of status

So called status bar is placed in the upper part of the screen. You may find here the information about time, battery level and signal but also other useful information. For example the information about new SMS, system or applications.

Status bar can be moved down by your finger or rolled. You

will get a detailed overview about all announcements and information including the possibility of a quick control of some mobile functions.

Mobile phone set up

All items of the telephone set up are clearly arranged at the settings menu. Press the button **Menu (1)** and select **Set up** .

Making calls

Dialling

Click on the earphone icon on the main screen. Screen with keypad for number dialling will be displayed.

You can enter the tel.number with the use of the keyboard buttons.

Similarly as on the common telephone there are the letters displayed on the buttons so you can enter also the name.

The dialled number and all corresponding items of the tel.directory will be displayed after entering of the letters on keys of the screen.

At the bottom part of the screen you may find the button for making calls (head-phone symbol). You can press

this button, dial selected number and make a call.

Choice of SIM card for calls

Click on the head-phone icon on the main screen.

Now you can display the offer (which SIM card will be used for calling) for your choice by dragging down of the status bar.

Answer and reject the call

If somebody is calling you the information about his telephone number (in available) and a button with

the receiver is displayed on the screen.

To **answer** the call : move the button to the right towards the symbol of a green receiver .

Call flow and finish of the call

The screen will automatically switch off when the mobile phone is attached to the ear. After the delay from the ear the screen will switch on within few seconds.

The **call can be finished** by pressing of the **red** button on the screen.

Messages

1. Click on the icon of Messages on the lower side of the main screen or open the screen with applications and select the item **SMS a MMS**.
2. A list of conversations containing received and sent SMS and MMS messages will be displayed.
3. Select the icon New message on the left bottom side of the screen.

4. Now you can insert the receiver of the text message.
5. To **send the text message** press the arrow button placed on the right side of the text.

Same as by calling you can choose by dragging down of the status bar which SIM card can be used for sending of messages.

Choice of SIM for data connection


You can choose which SIM card will be used for a internet speed data connection :

- Press the icon **Setup** on the main screen
- Select **SIM cards**
- Continue to select **Mobile data**
- Choose which SIM card will be used

Photography

Press the icon „Camera“ to start the photography. Focus the camera on the subject of the shot.


Aim the camera at the scene and tap your finger on the screen to the point that you want to focus on or wait a moment, the camera automatically focuses on the center.


After focusing the scene, you can take a picture by pressing the shutter  button on the side of the display. Every few seconds, in case of the change of scene, the camera will automatically focus on the center of the image.

if you want to accelerate focusing or to focus on a different part of the image, tap

the desired location on the screen.

Beware! Always wait for focus and then press the shutter button, otherwise the images will be blurred.

Press the button  to switch the front and rear camera.

Press the button  to shoot the video.

PC connection

You do not need any special driver (valid for OS Windows Vista, 7, event. newer) for the connection to the common PC. Follow these steps :

Connect the mobile phone and your PC with the enclosed cable

The mobile phone will be connected with the PC as „Media Devices“

Now the internal storage at the mobile phone and inserted MicroSD card will be connected with the PC at the file Computer, in section Portable Devices , under the name ALIGATOR S5080.

The connection can be interrupted by disconnection of the cable.

Smart casing

Smart casing with a window can be bought as an accessories to the mobile phone. The phone is able to detect when the housing is open and when closed.

After closing of the casing, the phone automatically locks the screen and after you press the power button (5) the time, date information and missed calls display at the window of the casing.

Swiping your finger across the screen to the left you can view the text of received SMS and swiping to the right you can display track information with the possibility to control the player.

Incoming calls can be accepted directly in the window without opening the sleeve - the caller's information and a

button to answer or reject the call are displayed in the window.

After opening the case, the phone automatically unlocks. This feature can be enable or disabled at the phone settings section Display – Unlock by opening of the housing.

Troubleshooting

Under certain circumstances (eg. if the opened part of the housing is pressed against the back of the phone, covering some sensors by hand etc.) and the action of environmental influences, can lead to false positives closing or opening the case.

It is therefore possible to set off the function of the smart sleeve. If you have a problem with incorrect evaluation of opening / closing of the housing, turn off the settings in the **Display - Smart case.**

When using the smart casing the sensor function of the e-compass (if included with the phone) will not work correctly. This is due to the presence of a magnet which is used in a smart housing to detect open / close.

Safety and ecology



Used electric device

Mobile phone is an electronic appliance. It means it must not be manipulated as a common residential waste. **Never throw the used device away at the common municipal waste!!!** They may contain the substances dangerous to the environment. Hand over the battery to the respective collection point which provides the ecological liquidation. Please contact your dealer to get more information how to deal with the used products.

Battery liquidation



Used/old batteries and accumulators do not belong to the common residential waste !!!

They may contain the substances dangerous to the environment. Hand over the battery to the respective collection point which provides the ecological liquidation. Please contact your dealer to get more information how to deal with the used products.

Handling with the used batteries in contradiction with given instructions is illegal!

Do not throw the battery in the fire nor expose it to the temperatures over +60°C. Danger of explosion or fire.

CE 1313

Declaration of conformity

No.30/09/2015

Issued in accordance with the prescription EU R&TTE, 1999/5/EC

Product: Mobile phone for GSM network

Model : Aligator S5080 Duo

Importer: ADART COMPUTERS s.r.o.,
Sokolovská 161, 180 00 Praha 8, Reg.No. 25074547
Evaluated product is a mobile phone intended for mobile nets of GSM standard and is planned to be used and stored in standard conditions.

The importer declares, that the product is for its use safe and during the production there are taken control and other measurements securing the conformity of the product with the basic requirements and technical documentation.Relevant harmonized norms have been applied to evaluate the conformity.The tests were carried out and the protocol made by authorised person: Bay Area Compliance Laboratories Corp., 1274 Anvilwood Ave., Sunnyvale, CA 94089, USA
Issued in Prague, on 30.09.2015



.....
ADART COMPUTERS s.r.o.